

# HydraFlex<sup>™</sup> Waterproofing Crack Isolation Membrane



## **1. PRODUCT NAME**

TEC<sup>®</sup> HydraFlex<sup>™</sup> Waterproofing Crack Isolation Membrane (316)

## **2. MANUFACTURER**

H.B. Fuller Construction Products Inc. 1105 South Frontenac Street Aurora, IL 60504-6451 U.S.A. 800.552.6225 Office 800.952.2368 Fax tecspecialty.com

## **3. DESCRIPTION**

Ready-to-use, flexible, mold and mildew resistant waterproofing crack isolation membrane for interior and exterior applications. Forms a smooth, monolithic, watertight surface over walls, floors and ceilings. HydraFlex<sup>TM</sup> Membrane stops in-plane cracks up to  $\frac{1}{8}$ " (3 mm) or up to  $\frac{1}{4}$ " (6 mm)\* wide at the subfloor from telegraphing through to ceramic and stone tile. For residential to extra heavy commercial applications.

\*Based on application

## **Key Features and Benefits**

- Exceeds ANSI A118.10 Specifications for Waterproof Membranes
- Exceeds ANSI A118.12 Specifications for Crack Isolation Membranes
- Use for Positive Hydrostatic Pressure Applications
- Fast Drying ready for tile installation in 1 to 3 hours
- Easy roller, trowel or spray application
- No mesh required (except for waterproofing installations at changes in-plane and substrate joints)
- Apply over new (green) concrete as little as 3 days old
- Isolates cracks up to 1/8" (3 mm) or up to 1/4" (6 mm) based on application
- · Membrane resistant to growth of mold and mildew
- IAPMO approved
- Approved over control joints
- Contributes to LEED® project points
- Low VOC

#### Packaging

 One U.S. gallon plastic pails (3.78 L)
 Product #7002745011

 3.5 U.S. gallon plastic pails (13.24 L)
 Product #7002741211

 5 U.S. gallon plastic pails (18.93 L)
 Product #7002741511

 TEC® Waterproofing Mesh available in:
 6 in. x 50 ft. rolls (150 mm x 15.24 m)
 Product #3317599011

#### Coverage

Application	Required Coats	Wet Film Thickness (mils)	Approximate Coverage per Gallon
1/8" (3 mm)	1	25 mils [.025" (.6 mm)]	100 sq. ft. (9.29 m <sup>2</sup> )
1/4" (6 mm)	1	50 mils [.05" (1.27 mm)]	50 sq. ft. (4.65 m <sup>2</sup> )
Waterproofing	2	1st Coat - 25 mils [.025" (.6 mm)] 2nd Coat - 25 mils [.025" (.6 mm)]	50 sq. ft. (4.65 m²)

#### **Suitable Substrates**

When properly prepared, suitable substrates include:

- Concrete (minimum 3 days old), cured mortar beds and masonry (interior or exterior)
- Gypsum wallboard (interior), cementitious backer units (CBU or cement board. Interior or exterior)
- APA Grade Trademarked Exposure 1 Plywood [CDX or better; two layers, 1<sup>1</sup>/<sub>8</sub>" (28 mm) total minimum thickness, interior floors only]
- · Gypsum underlayment (minimum compressive strength 2000 psi)
- Existing ceramic tile, VCT or non-cushioned sheetgoods provided they are single layer only and well bonded to a substrate approved for tile (interior)
- · Adhesive residue (except tacky or pressure-sensitive adhesive, interior only)
- Cold rolled steel

#### **Substrate Preparation**

Application surfaces must be free from oil, grease, dust, paint, concrete sealers, floor finishes or curing compounds. New concrete shall be finished with a steel trowel, have a fine broom finish, and must cure a minimum of 3 days. For high moisture vapor emission concrete applications, the maximum acceptable moisture vapor emission rate is 12 pounds per 1000 square feet (5.4 kg per 92.9 m<sup>2</sup>) per 24 hours when evaluated by ASTM F1869 or 90% relative humidity per ASTM F2170. Where required, existing concrete surfaces shall be prepared by mechanical method such as scarifying, grinding, sand blasting or shot blasting. Surface protrusions and tile glazes will be removed by sanding, scraping or scarifying. After preparation, remove all dust by vacuuming. Clean concrete floor from dust with a wet sponge and let the floor dry completely before membrane application. Note: Vinyl asbestos tile or any substrate containing asbestos must not be sanded, scored or scarified because of the potential health hazard of breathing dust. Any substrate containing asbestos must be handled in accordance with existing EPA regulations. Contact your local EPA office. Patch and fill holes and voids with an appropriate TEC® surface preparation product. Treat existing building construction, contraction (control), expansion or isolation joints as required in the following installation instructions. Provide movement joints in the tile where specified.

#### Storage

Store in cool, dry location. Do not store open containers, nor leave containers exposed to sunlight. Product must be kept at temperatures of  $40^{\circ}-90^{\circ}F$  ( $4^{\circ}-32^{\circ}C$ ). Keep from freezing.

## Shelf Life

Maximum of 1 year from date of manufacture in unopened package.

#### Limitations

- Not for use as a wear surface.
- Do not apply over wet areas.
- Do not use over dimensionally unstable substrates such as particle board, pressboard, lauan plywood, waferboard, tempered hardboard (e.g. Masonite) or fiberglass.
- Do not use in areas subject to hydrostatic pressure from beneath the membrane.
- For exterior wall applications, refer to local building codes for moisture vapor transmission requirements.

## Cautions

Read complete cautionary information printed on product container prior to use. For medical emergency information, call 1-888-853-1758.

This Product Data Sheet has been prepared in good faith on the basis of information available at the time of publication. It is intended to provide users with information about and guidelines for the proper use and application of the covered TEC<sup>®</sup> brand product(s) under normal environmental and working conditions. Because each project is different, H.B. Fuller Construction Products Inc. cannot be responsible for the consequences of variations in such conditions, or for unforeseen conditions.

## **4. TECHNICAL DATA**

## **Applicable Standard**

Exceeds ANSI A118.10 Specifications for Waterproof Membranes Exceeds ANSI A118.12 Specifications for Crack Isolation Membranes

HydraFlex™ Waterproofing Crack Isolation Membrane (316)				
Description	ANSI A118.10 Requirement	Typical Results		
Shear Strength 7-Day 7-Day, Water Immersion 4-Week 12-Week 100-Day, Water Immersion	50 psi (0.34 MPa) 50 psi (0.34 MPa) 50 psi (0.34 MPa) 50 psi (0.34 MPa) 50 psi (0.34 MPa)	238 psi (1.63 MPa) 150 psi (1.03 MPa) 310 psi (2.12 MPa) 330 psi (2.26 MPa) 125 psi (0.86 MPa)		
Fungus Resistance	Shall not support mold growth	Passes		
Seam Strength	8 lb./inch width	> 20 lb./inch width (> 3.6 lg/cm)		
Breaking Strength	Minimum 170 psi (1.17 MPa)	250 psi (1.72 MPa)		
Dimensional Stability	Maximum 0.7% length change	< 0.7% length change		
Waterproofness Tested in accordance with American Standards for Load Bearing, Bonded, Waterproof Membranes for Thin Set Ceramic Tile and Dimension Stone Installations—ANSI A118.10	No visible water penetration after 48 hours	Passes		
Description	ANSI A118.12 Requirement	Typical Results		
Point Load	Minimum 1000 lb. load without cracking tile	Passes		
Shear Deflection	Standard Performance Min. <sup>1</sup> ⁄16" (1.6 mm) High Performance Min. <sup>1</sup> ⁄8" (3 mm)	High Performance		
Crack Resistance Test	Standard Performance Min. ¼6" (1.6 mm) High Performance Min. ¼" (3 mm)	High Performance		
Additional Tests	Test Method	Typical Results		
Accelerated Test for Fungal Defacement	ASTM D5590	Passed with no growth and 10 mm zone off inhibition.		
Water Vapor Permeance	ASTM E96 Procedure B	1.5 perms (85.8 ng/PA⋅s⋅m²)		
Elongation	ASTM D751	750%		
Tensile Strength	ASTM D751	250 psi (1.72 MPa)		

## **Physical Properties**

Description		
Physical State	Liquid: Acrylic Emulsion Modified with a Polyurethane Dispersion Waterproofing Mesh: Non-hazardous Fibrous Mesh	
Color	Cured: Purple	
Odor	Cured: None Uncured: Mild Ammonia	
Tile Installation Time [at 70°F (21°C)]	1-3 hours after membrane application. See CURING section for more information.	
Foot Traffic Rating (ASTM C627)	Residential to Extra Heavy Commercial (depending on substrate)	
Service Temperature Rating	-20°F (-29°C) to 320°F (160°C)	
VOC (less water)	12 g/L	
Storage	Store in cool, dry location. Do not store open containers, nor leave containers exposed to sunlight. Keep from freezing.	
Shelf Life	Maximum 1 year from date of manufacture in properly stored, unopened package.	
Freeze/thaw Stability of Liquid	None. KEEP FROM FREEZING.	

## **5. INSTALLATION INSTRUCTIONS**

## INSTALLATION INSTRUCTIONS AS WATERPROOFING MEMBRANE

#### Application—Waterproofing Membrane

To achieve waterproofing properties, a continuous membrane (no voids) of at least 46-50 mils [ $\frac{3}{44}$ " (1.14-1.27 mm)] wet film thickness is required over the entire surface. Pre-fill all concrete cracks and plywood gaps up to  $\frac{1}{8}$ " (3 mm) wide with membrane prior to application. Treat cracks greater than  $\frac{1}{4}$ " (6 mm) wide as expansion joints (see following section).

Apply membrane to entire surface using a  $\frac{1}{4}$ " to  $\frac{1}{2}$ " (6-12 mm) nap roller,  $\frac{3}{16}$ " (4.7 mm) v-notch trowel, or airless sprayer\*. For waterproofing installations, membrane must be applied in two coats. Apply first coat, measuring membrane periodically with a wet film thickness gage to ensure a minimum thickness of 25 mils wet. Allow first coat to dry approximately 1 hour, until membrane changes to a semi-transparent color. Then apply second coat at right angles to the first coat. An additional 25 mils wet film thickness shall be applied to achieve a combined total thickness of 50 mils wet, curing to a dry film thickness of 30 mils.

\* Graco<sup>®</sup> Electric Airless Sprayer Model 390 or equivalent. Specifications: 0.020 Maximum Nozzle Orifice, Maximum Sprayer Pressure 3,300 psi, flow rate of 0.43 gallons per minute, Contractor FTX11 Gun, RACX 515 Tip & Guard. Graco is a trademark of Graco Inc.

#### Application—Mesh (Flashing)

Flashing with TEC<sup>®</sup> brand Waterproofing Mesh is required at all substrate joints; field seams; inside corners; outside corners; anywhere vertical surfaces meet horizontal surfaces such as curbs, bench seats, columns, etc.; or anywhere dissimilar materials meet. Flashing is also required for drains and expansion/ control joints.

To accomplish flashing, first pre-coat the substrate intersections 4" (100 mm) on each side. Then fully embed the 6" (150 mm) wide waterproofing mesh in both directions into the pre-coated areas with a 3" (76 mm) overlap on each side. Allow to dry (approximately 30 to 45 minutes) before full application of membrane.

## **Application—Joint Details**

**Control joints [typically ¼" (6 mm) or smaller]:** Ensure joint is clean and free of all debris. Then fill the joint with membrane and spread to 4" (100 mm) on either side, embedding the waterproofing mesh. Install the membrane over the entire surface ensuring a continuous 50 mil wet film thickness. For treatment of cracks or control joints where HydraFlex® Waterproofing Crack Isolation Membrane is not applied over the entire substrate, see Technical Bulletin "Treatment of INDIVIDUAL Concrete Cracks with TEC® Products" on tecspecialty.com.

#### Fig. 1: Pretreatment of Cracks or Control Joint with TEC® HydraFlex™ Waterproofing Crack Isolation Membrane



**Expansion, Isolation, and Construction Joints:** Ensure joint is clean and free of all debris. Install compressible backer rod (open or closed cell backer rod) into the joint. Next compress the specified sealant into the joint according to the sealant manufacturer's printed installation instructions, leaving it flush with the surrounding surface. After the sealant has cured, cover the joint with bond breaker tape. Apply membrane as directed, making sure to embed the 6" (150 mm) wide waterproofing mesh centered over the joint, with a 3" (76 mm) overlap on either side. After installing the membrane over the entire surface ensuring a continuous 50 mil wet film thickness and required cure time, place bond breaker tape over the joint and install tile without bridging the joint. After the tile has been installed, caulk the joint with specified sealant.

## TEC<sup>®</sup> HydraFlex<sup>™</sup> Waterproofing Crack Isolation Membrane

#### Application—Drain Details

HydraFlex<sup>™</sup> must extend to the bottom of the drain flange, with sufficient coverage to channel all water flow to and down the drain. DO NOT cover weep holes with membrane. The following diagram depicts a typical drain configuration:

#### Fig. 2: Drain Configuration



**Note:** This diagram is provided to show a typical drain detail and is not intended to make specific design recommendations.

Install a continuous membrane to cover the substrate and up to the drain opening, making sure to embed the waterproofing mesh around the drain opening, as shown in the diagram. Once the membrane has dried thoroughly, the flange should then clamp down on the membrane, with the weep holes unobstructed. (See TCA Installation Methods for shower receptors).

#### Clean-up

Clean tools, hands and excess material immediately (while still fresh) with water. Material that is cured is difficult or impossible to remove.

#### **Curing/protection**

HydraFlex<sup>™</sup> membrane is typically ready for tile application in 1-3 hours. Cure times based on 70°F (21°C) and 50% RH. Colder temperatures, higher humidity or green concrete (not fully cured) will extend cure times. In all cases, care should always be taken to not gouge or otherwise disturb or damage the integrity of the cured membrane.

Inspect cured film to make sure there are no voids, bubbles or breaks in the membrane. Apply additional membrane to fill all voids. If water testing is desired/ required prior to tile installation, allow membrane to cure at least 12 hours after application of second coat. Plug all drains and dam the floor area to be tested. Flood the area to a meaningful test level and place a mark at the initial water level. Check the area carefully, looking for any signs of leakage (air bubbles rising from the leak source). After 24 hours, check water level against mark(s) made at initial height. If significant loss has occurred, further investigation will be necessary to identify leaks.

Install tile using a suitable TEC<sup>®</sup> latex-modified mortar or TEC<sup>®</sup> AccuColor EFX<sup>®</sup> Epoxy Grout and Mortar.

## INSTALLATION INSTRUCTIONS AS CRACK ISOLATION MEMBRANE

Pre-fill all concrete cracks, control joints and plywood gaps up to 1/8" (3 mm) wide with membrane prior to application. For expansion, isolation and construction joints continue joints through the tile installation in accordance with Installation Method EJ171 in the Tile Council of America handbook. Treat dynamic cracks (subjected to movement) greater than 1/4" (6 mm) wide as expansion joints.

#### <sup>1</sup>/<sub>8</sub>" Crack Isolation Applications:

Apply membrane to entire surface using a  $\frac{1}{2}$ " to  $1\frac{1}{4}$ " (12-31 mm) synthetic nap roller,  $\frac{1}{8}$ " (3 mm) v-notch trowel, or airless sprayer\*. Membrane may be applied in one coat. Measure membrane periodically with a wet film thickness gage to ensure a minimum thickness of 25 mils [.025" (.6 mm)] wet, curing to a dry film thickness of 15 mils [.015" (.4 mm)].

\* Graco® Electric Airless Sprayer Model 390 or equivalent. Specifications: 0.020 Maximum Nozzle Orifice, Maximum Sprayer Pressure 3,300 psi, flow rate of 0.43 gallons per minute, Contractor FTX11 Gun, RACX 515 Tip & Guard. Graco is a trademark of Graco Inc.

#### <sup>1</sup>/<sub>4</sub>" Crack Isolation Applications:

Membrane may be applied in one coat to entire surface. Measure membrane periodically with a wet film thickness gage to ensure a minimum thickness of 50 mils wet, curing to a dry film thickness of 30 mils.

Note: When using a V-notch trowel for crack isolation applications, "key in" a thin coat of membrane using the flat side of the trowel. Immediately afterwards, apply additional material using the notched side of the trowel held at approximately a 45 degree angle to the substrate. Again using the flat side of the trowel, flatten the ridges to form a smooth, continuous membrane.

Waterproofing mesh is not required for crack isolation applications.

#### Curing

Cure for 1-3 hours. Cure times based on 70°F (21°C) and 50% RH. Thicker films, cooler temperatures, higher humidity or green concrete (not fully cured) will extend cure times.

Install tile using a suitable  ${\sf TEC}^{\circledast}$  latex-modified mortar or  ${\sf TEC}^{\circledast}$  AccuColor  ${\sf EFX}^{\circledast}$  Epoxy Grout and Mortar.

#### Clean-up

Clean tools, hands and excess material immediately (while still fresh) with water. Material that is cured is difficult or impossible to remove.

## **6. AVAILABILITY**

TEC<sup>®</sup> Premium Tile and Stone Installation Products are available nationwide. To locate TEC<sup>®</sup> products in your area, please contact:

Phone: 800-832-9002

Website: tecspecialty.com

## 7. WARRANTY

For warranty details, see your sales associate or tecspecialty.com.

## 8. MAINTENANCE

Not applicable

## 9. TECHNICAL SERVICES

## **Technical assistance**

Information is available by calling the Technical Support Hotline. Toll Free: 800-832-9023 Fax: 630-952-1235

#### Technical and safety literature

To acquire technical and safety literature, please visit our website at tecspecialty.com.

## **10. FILING SYSTEM**

Division 9



tecspecialty.com

©2017 H.B. Fuller Construction Products Inc. TEC<sup>®</sup>, TEC<sup>®</sup> logo, HydraFlex<sup>™</sup> and AccuColor EFX<sup>®</sup> are trademarks of H.B. Fuller Construction Products Inc. LEED<sup>®</sup> is a registered trademark of U.S. Green Building Council.

